

IQ 1.5 GENERAL HOT KEY LIST

F2	Datamangement Mode	↑	Previous Marker
F3	RealTime Mode	↓	Next Marker
F4	Post Process Mode		
F5	Modelling Mode	CTRL C	Copy
		CTRL V	Paste
SPACE	Maximise/Minimise View Pane	CTRL X	Cut
PAGE UP	Previous Activity Bar		
PAGE DOWN	Next Activity Bar	CTRL O	File Open
		CTRL S	File Save
DEL	Delete Selected Objects	D	Delete Marker at Current Frame
CTRL Z	Undo	CTRL D	Delete Inside Selected Range of Frames
CTRL Y	Redo	SHIFT D	Delete Outside Selected Range of Frames
		CTRL E	Exchange Trajectories
ALT MOUSE	Camera Control	CTRL B	Paste Pattern
F	Frame On Selected Objects	+	Add Point
CTRL F	Focus/Aim on Selected Objects	-	Delete and Fill Selected Range of Frames
SHIFT F	Frame ALL objects		
ALT F	Toggle Follow Mode On/Off	<	Set Left Selected Frame to Current Time
SHIFT V	Toggle View Options On/Off	>	Set Right Selected Frame to Current Time
L	Toggle Chase Camera On/Off		
→	Increment Current Time	I	Un-Label Selected Marker at Current Frame
←	Decrement Current Time	END	Un-Label Selected Marker at Current Frame
ALT →	Toggle Play Forwards	U	Un-Label Selected Trajectory
ALT ←	Toggle Play Backwards	S	Toggle Labelling Mode On/Off
SHIFT →	Increase Playback Speed	NUMPAD 0	Toggle Labelling Mode On/Off
SHIFT ←	Decrease Playback Speed		
ALT <	Decrease Displayed Trajectory Length		
ALT >	Increase Displayed Trajectory Length		

IQ 1.5 SEARCH TOOLS / MISCELLANEOUS HOT KEY LIST

CTRL →	Find End of Selected Trajectory
CTRL ←	Find Start of Selected Trajectory
F10	Find Next Unlabelled Trajectory
SHIFT F10	Find Previous Unlabelled Trajectory
F11	Find Next Points by Type in Selected Trajectory
SHIFT F11	Find Previous Points by Type in Selected Trajectory
CTRL F11	Find Next Points by Type in Trial
CTRL SHIFT F11	Find Previous Points by Type in Trial
F12	Find Next Spike in Selected Trajectory
SHIFT F12	Find Previous Spike in Selected Trajectory
CTRL F12	Find Next Spike in Trial
CTRL SHIFT F12	Find Previous Spike in Trial
F9	Find Next Gap in Selected Trajectory
CTRL F9	Find Previous Gap in Selected Trajectory
SHIFT F9	Find Next Gap in Trial
CTRL SHIFT F9	Find Previous Gap in Trial

G	Group Tracker Start (Labelling Only)
C	Continue Group Tracker (Labelling Only)

CTRL +	Add New Operation to Pipeline
CTRL -	Remove Selected Operation from Pipeline
CTRL ENTER	Run Pipeline From Selected Position

IQ 1.5 REALTIME HOT KEY ADDITIONS

+	Reset Labelling
---	-----------------

IQ 1.5 MODELLING HOT KEY ADDITIONS

M	Select Manipulate Mode On
S	Toggle Select/Manipulate Mode
N	Create New Rigid Body
P	Parameter Editor
ESC	Cancel current Editing Tool Mode

IQ 1.5 DATAMANAGEMENT HOT KEY ADDITIONS

CTRL +	Add Marked Trials to Batch Process
CTRL ENTER	Start Batch Process
CTRL END	Stop Batch Process
CTRL -	Remove Marked Trial from Batch Process